




AM 150, ceiling mounting

AIRMASTER



Measures in mm.

DWG.:1032234

	DK	NO	SE	DE	NL	FR
1	Afkast	Avkast	Avluft	Fortluft	Afvoer lucht	Rejet d'air vicié
2	Indtag	Tilluft	Uteluftintag	Außenluft	Verse lucht	Prise d'air extérieur
3	Indblæsning	Innblåsning	Tilluft	Zuluft	Inblaas	Air soufflé
4	Udsugning	Avtrekk	Frånluft	Abluft	Afzuig	Air repris
5	Loframme	Takramme	Takram	Deckenrahmen	Plafond frame	Cadre à fixation au plafond
6	Kondens afløb	Kondensavløp	Kondensavlopp	Kondensatablauf	Condensafvoer	Évacuation condensats
7	El-tilslutning	El-tilkobling	Elektrisk anslutning	Elektrischer Anschluss	Elektrische aansluitingen	Raccordement électrique
8	Status LED	Status LED	Status LED	Status-LED	Status-LED	LED d'état

AIRMASTER

Airmaster A/S
Industrivej 59
9600 Aars
Danmark

Tel.: +45 98 62 48 22
info@airmaster.dk
www.airmaster.dk



Helios Ventilateurs
Le Carré des Aviateurs
157 av. Charles Floquet
93155 Le Blanc Mesnil Cedex
France

Tél. +33 1 48 65 75 61
Fax. +33 1 48 67 28 53
info@helios-fr.com
www.helios-fr.com

Airmaster Norge AS
Brogata 7
2000 Lillestrøm
Norge

Tel. +47 99 08 04 44
info@airmaster-as.no
www.airmaster-as.no



SAV Systems
Scandia House, Boundary Road
Woking, Surrey
GU21 5BX
United Kingdom

Tel: +44 1483 771910
info@sav-systems.com
www.sav-systems.com

Airmaster Belgique
Santvoortbeeklaan 23B
2100 Deurne
Belgique

Tel.: +32 (0) 4 70 11 26 33
info@airmaster.be
www.airmaster-as.com/fr



Johann Wernig KG
Unterbergen 40
9163 Unterbergen im Rosental
Österreich

Tel. +43 4227 2213-0
Fax. +43 4227 3564
office@wernig.at
www.wernig.at

Airmaster B.V.
Lage Mosten 49
4822 NK Breda
Nederland

Tel.: +31 10 307 06 25
info@airmaster-bv.nl
www.airmaster-as.com/nl



WESCO AG
Tägerhardstrasse 110
5430 Wettingen
Schweiz

Tel. +41 56 438 12 12
Fax. +41 56 438 12 10
airmaster@wesco.ch
www.wesco.ch